


WINMAU®

THE FORCE BEHIND DARTS™

POLARIS


120° DARTBOARD LIGHT

INSTRUCTION MANUAL




CONTENTS

- A - Light arc (x1)
- B - Leg (x4)
- C - Adapter kit (x1)
- D - M4x12mm bolt (x8)
- E - M4 washer (x8)
- F - M4 nut (x8)
- G - Spanner (x1)
- H - Cable clip (x2)
- I - Cable ties



ASSEMBLY

1. Attach 4 legs (B) to the inside of the light arc (A) using bolts (D), washers (E) and nuts (F). Tighten nuts using spanner provided (**see diagrams**).
2. Use the cable ties (I) and clips (H) provided to secure the cable.
3. Connect the cable to mains power using the adapter supplied (C).
4. Ensure to remove the light when turning the dartboard.



FITTING WITHOUT SURROUND

1. Place on top of dartboard and ensure each magnet is in contact with the metal band around the outside of the board.
2. Centralise the light on the board.



FITTING WITH SURROUND



1. Place the surround over the light (**see diagram**).
2. Place on top of dartboard and ensure each magnet is in contact with the metal band around the outside of the board. (**see diagram**)

3. Move the surround over the legs onto the board. (**see diagram**)
4. Connect the cable to mains power using the adapter supplied (**C**).
5. Ensure to remove the light when turning the dartboard.



WINMAU®

THE FORCE BEHIND DARTS™

Winmau Dartboard Company Ltd.
South Road, Bridgend Industrial Estate,
Bridgend, CF31 3PT, UK

Tel: +44(0) 1656 767042

winmau.com
info@winmau.com

